

TAKSTAR® 得胜



演讲麦 | DA8

SPEECH MICROPHONE

使用手册 User Manual

■ 前言

尊敬的用户：

感谢您选购得胜DA8演讲麦，为了您能够更好地了解使用本产品，建议您在使用前仔细阅读本说明书。

若存在有疑问或者您有宝贵的建议，可通过拨打得胜官方服务热线400 6828 333或微信扫描二维码关注得胜官方公众号与我们联系。



■ 产品特性

- 手持便携扩音器，集麦克风与音箱一体，告别复杂设备；
- 小蛮腰人体工学设计，握感舒适，迷你轻便易收纳；
- 选用全音域喇叭，高保真音质，久听护耳、声音清晰；
- DSP防啸叫芯片，精准抑制啸叫杂音，拾音轻松，保护嗓子；
- 智能待机设计，闲置45分钟自动关机，杜绝空耗省电耐用；
- 内置大容量锂电池，充电3小时，使用时间约8小时；
- 支持无线音频播放，摆脱线材束缚，畅享音乐更自由。

■ 适用范围

适用于演讲、教学、宣传、K歌等场合

DA8 演讲麦

■ 产品配置

DA8演讲麦.....	1个
Type-C充电线.....	1条
挂绳.....	1条
说明书.....	1份

■ 技术参数

主机参数

- 喇叭规格:50mm
- 频率响应:150Hz-12kHz
- 峰值功率:12W
- 扬声器阻抗:4Ω
- 总谐波失真:THD≤5%
- 信噪比:80dB(A-Weighted)
@4R,3W
- 电池类型:锂离子电池
- 电池规格:3.7V/2000mAh
- 充电规格:5V=1A
- 充电时间:约3小时
- 工作电压范围:3.4V-4.2V
- 使用时间:约8小时
- 产品重量:约182g
- 产品尺寸:Φ68mm*202mm
(直径*高)

音头参数

- 拾音器:背极式驻极体
- 指向性:超心型
- 频率响应:60Hz-16kHz
- 灵敏度:-42±2dB (0dB=1V/Pa, at 1kHz)

注:以上数据由得胜实验室测试得到,并拥有最终解释权!

■ 功能示意

② 数码显示屏

显示电池电量、音量等工作信息

⑤ Type-C接口

④ 音量“-”


点按音量-, 长按下一曲

③ 音量“+”

点按音量+, 长按上一曲

① 电源键

长按开/关机, 点按切换4种模式, 双击返回演讲模式



- ① 电源键: 长按2秒开机或关机; 点按切换4种模式: 演讲模式、主持模式、K歌模式、音乐模式; 双击快速返回演讲模式; 在任何工作模式下, 无使用45分钟后自动关机。
- ② 数码显示屏: 显示当前电池电量百分比、音量大小、工作状态等信息。
- ③ 音量+键: 点按增加音量, 有“00-05”共6级音量调节; 在K歌、音乐模式下, 长按切换上一曲。
- ④ 音量-键: 点按减少音量, 有“00-05”共6级音量调节; 在K歌、音乐模式下, 长按切换下一曲。
- ⑤ Type-C接口: 连接Type-C充电线为演讲麦充电。

■ 使用说明

一、无线连接配对方法

首次使用无线连接功能时，需要与手机或其他智能设备配对连接，操作步骤如下：

1. 演讲麦开机后，点按电源键切换到K歌或音乐模式，自动进入搜索配对，屏幕显示“BL”闪烁；
2. 打开手机的无线连接功能，搜索“TAKSTAR DA8”并点击连接，成功后伴有提示音；
3. 下次开机后，如果是已进行过无线连接，将自动回连最后一次使用的设备；
4. 按住-键，再点按电源键可断开无线连接。

二、充电与电量指示

状态	屏幕显示
开机状态	充电中：⚡符号闪烁，CH符号常亮
	充满电：⚡符号常亮，电量显示100%
关机状态	充电中：⚡符号闪烁
	充满电：⚡符号常亮

提示：初次使用时，建议先充满电；当电池充满时，请停止对电池充电，避免电池过充；如长时间不用，需每半年充电一次，避免电池过放，对电池性能产生影响。

三、握持示意图



握持示意图

■ 安全警示

为避免电击、高温、着火、辐射、爆炸、机械危险以及使用不当等可能造成的人身伤害或财产损失,使用本产品前,请仔细阅读并遵守以下事项:

1. 使用产品时请确认所连设备与本产品是否匹配以及合理调整音量大小,不要在超过产品功率及大音量下长时间使用,以免造成产品异常;
2. 使用中若发现有异常(如冒烟、异味等),请立即关闭电源开关并拔掉电源插头,然后将产品送售后服务网点检修;
3. 消费者若使用电源适配器供电,则应购买配套使用获得CCC认证并满足标准要求的电源适配器;
4. 本产品及配件都应放置在室内干燥通风处,请勿长期存放在潮湿、灰尘多的环境,使用中避免靠近火源、雨淋、进水、过度碰撞、抛掷、振动本机及覆盖通风孔,以免损坏其功能;
5. 若产品需要固定于墙壁或天花板时,请确保固定到位,防止因固定强度不足导致产品发生跌落危险;
6. 使用该产品时需遵守相关安全规定,法律法规明确禁止使用场合请勿使用本产品,以免导致意外事故;
7. 请不要自行拆机改装或维修,以防止出现人身伤害,如有问题或服务需求请联系当地售后服务网点跟进处理。

■ 关于图标含义解释



根据RL2004/108/EG和European Low Voltage Directive (欧洲低电压指令) RL2006/95/EG的测试结果表明, 本产品符合欧共体关于电磁兼容性的成员国法律整合的指令中所规定的限值。



未经合规方明确批准的变更或修改可能会使用户失去操作设备的权限。此设备符合FCC规则第15条部分的要求。操作须符合以下两个条件: (1) 此设备可能不会造成有害干扰, (2) 此设备必须接受接收到的任何干扰, 包括可能导致意外操作的干扰。



此符号表示, 根据WEEE指令(2012/19/EU)和国家法律, 由于这种类型的废弃物会有潜在的有害物质, 可能对环境 and 人类健康产生负面影响, 所以本产品不应与您的家庭垃圾一起处置, 应将本产品交由授权的电气和电子设备 (WEEE) 回收站回收。同时, 您在正确处理本产品的同时将有助于自然资源的有效利用。如需了解更多有关您可以在何处放置废物回收设备的信息, 请联系您当地的的城市办事处、废物管理局或家庭废物处理服务部门。

■ 关于本说明书

本说明书中内容符合截止印刷之日的技术规格。由于得胜公司会不断改进产品, 本说明书可能不符合您的特定产品的技术规格。要获取最新版说明书, 请访问得胜官网, 然后下载说明书文件。技术规格、设备或另售的附件在各个地区可能有所不同, 如有问题请与当地得胜销售网点确认。如需更多支持和深层产品信息, 请浏览得胜官方网站: <https://www.takstar.com>

版权所有 ©2026 得胜。得胜、TAKSTAR及其各自标志是得胜公司在中国和/或其他国家/地区的注册商标或商标。所有其它商标均是其各自所有者的财产。

■ 环保说明

产品中有毒有害物质或元素的名称及含量标识表

有毒有害物质或元素										
部件名称	铅 (Pb)	汞 (Hg)	镉 (Cd)	六价铬 (Cr(VI))	多溴联苯 (PBB)	多溴二苯醚 (PBDE)	邻苯二甲酸 二正丁酯 (DBP)	邻苯二甲酸 二异丁酯 (DIBP)	邻苯二甲酸 丁基苯酯 (BBP)	邻苯二甲酸 二(2-乙基)己酯 (DEHP)
塑料部件	○	○	○	○	○	○	○	○	○	○
金属部件	×	○	○	○	○	○	○	○	○	○
电路板组件	×	○	○	○	○	○	○	○	○	○
线缆	×	○	○	○	○	○	○	○	○	○
注1: ○ :表示该有害物质在该部件所有均质材料中的含量均不超过电器电子产品有害物质限制使用国家标准要求。 × :表示该有害物质至少在该部件的某一均质材料中的含量超出电器电子产品有害物质限制使用国家标准要求。 注2: 以上未列出的部件,表明其有害物质含量均不超过电器电子产品有害物质限制使用国家标准要求。										
此标志为产品的环保使用期限标志, 且此环保使用期限只适用于产品正常工作温度和湿度等条件。										





■ Preface

Dear Customer,

Thanks for purchasing our product. Read this manual thoroughly to use the product properly.

If you have any questions or suggestions, please contact our local sales service.

■ Features

- All-in-one portable handheld voice amplifier with integrated mic & speaker, no complex equipment needed.
- Ergonomic slim-waist design, comfortable grip, compact and lightweight for easy storage.
- Full-range speaker delivers clear, hi-fi sound, ear-friendly for prolonged use.
- DSP anti-feedback chip precisely suppresses howling and noise, ensures easy sound pickup and throat protection.
- Smart standby with 45-minute auto power-off when idle, power-saving and durable.
- Built-in high-capacity lithium battery: 3-hour charge for approx. 8 hours of runtime.
- Supports wireless audio playback for cable-free, unrestricted music enjoyment.

■ Applications

For speeches, teaching, promotions, and karaoke.

■ Package Contents

- 1 × DA8 Speech Mic
- 1 × USB-C Charging Cable
- 1 × Lanyard
- 1 × User Manual

■ Specifications

Speech Microphone


- Speaker: 50mm
- Frequency Response: 150Hz-12kHz
- Peak Power: 12W
- Speaker Impedance: 4Ω
- Total Harmonic Distortion: THD≤5%
- Signal-to-Noise Ratio: 80dB (A-Weighted) @ 4R, 3W
- Battery Type: Lithium-ion Battery
- Battery Capacity: 3.7V/2000mAh
- Charging Spec: 5V=1A
- Charging Time: Approx. 3 hours
- Operating Voltage Range: 3.4V-4.2V
- Operating Time: Approx. 8 hours
- Product Weight: Approx. 182g
- Product Dimensions: Φ68mm × 202mm (Dia. × Height)

Microphone Capsule

- Transducer: Back-electret Condenser
- Polar Pattern: Supercardioid
- Frequency Response: 60Hz-16kHz
- Sensitivity: $-42 \pm 2\text{dB}$ (0dB=1V/Pa, at 1kHz)

Note: The above data are measured by Takstar laboratory which has the final interpretation right!

Function Descriptions

- 
- The diagram shows a sleek, black, tapered microphone. At the top is a mesh grille. Below it, the brand name 'TAKSTAR' and a '100%' battery indicator are visible. Further down are three circular buttons: a '+' sign, a '-' sign, and a power symbol. The microphone has a wide base with two small feet.
- ② **Digital Display**
Displays battery level, volume and other operating information.
- ⑤ **USB-C Charging Port**
- ③ **Volume + Button**
Press to increase volume; long press for previous track.
- ④ **Volume - Button**
Press to decrease volume; long press for next track.
- ① **Power Button**
Long press to power on/off; press to switch between 4 modes; double-click to return to speech mode.
- ① **Power Button:** Long press 2s to power on/off; press to switch among 4 modes (Speech, Host, Karaoke, Music); double-click to quickly return to speech mode. Auto power-off after 45 minutes of inactivity in any working mode.

- ② Digital Display: Shows current battery percentage, volume level, working status and other information.
- ③ Volume + Button: Press to increase volume, 6 adjustable levels (00-05); long press for previous track in karaoke/music mode.
- ④ Volume - Button: Press to decrease volume, 6 adjustable levels (00-05); long press for next track in karaoke/music mode.
- ⑤ Type-C Port: Connect a Type-C charging cable to charge the speech microphone.

■ Operating Instructions

I. Wireless Connection Pairing

To use the wireless connection feature for the first time, pair it with your phone or other smart devices as follows:


1. After powering on, press the power button to switch to karaoke or music mode, entering search pairing mode; the screen shows a flashing "BL".
2. Enable the wireless connection on your phone, search for "TAKSTAR DA8", and tap to connect. A prompt sound will indicate success.
3. On subsequent power-ups, if a wireless connection has been made before, it will automatically reconnect to the last used device.
4. Press and hold the "-" button, then press the power button to disconnect the wireless connection.

II. Charging and Battery Indication

State	Screen Display
Power On State	Charging: Symbol ⚡ flashes, CH symbol stays solid.
	Fully Charged: Symbol ⚡ stays solid and battery level shows 100%.
Power Off State	Charging: Symbol ⚡ flashes.
	Fully Charged: Symbol ⚡ stays solid.

Note: For first-time use, it is recommended to fully charge the battery first. When the battery is fully charged, please stop charging it to prevent overcharging. If not in use for a long time, charge it once every six months to avoid over-discharging, which may affect battery performance.

III. Grip Diagram



Grip Diagram

■ Safety Instructions

To avoid electric shock, overheat, fire, radiation, explosion, mechanical risk and injury or property loss due to improper use, please read and observe the following items before use:

1. Please check if the power of the connected equipment matches with that of this product before operation. Adjust the volume to proper level during operation. Do not operate at over-power or high-volume level for extended time to avoid product malfunction.
2. If there is any abnormality during use (e.g., smoke, strange odor), please kill the power switch and unplug from power source, then send the product to the local after-sales service for repair.
3. Power adapter used, if any, should be approved by CCC certification or similar standards and comply with the power supply requirements.
4. Keep this product and its accessories in a dry and ventilated area. Do not store in a humid or dusty area for extended time. Keep away from fire, rain, liquid intrusion, bumping, throwing, vibrating, or from blocking any ventilation openings, to prevent malfunction.
5. The product must, when installed on walls or ceilings, be fixed firmly in place at adequate strength to prevent from falling.
6. Please abide by safety rules during operation. Do not use the product in places prohibited by laws or regulations to avoid accident.
7. Do not disassemble or repair the product unauthorized to avoid injury. If you have any questions or require any services, please contact our local after-sales service.

■ Label Meanings

 This device is compliant with the limits of the European Council Directive on the approximation of the laws of the member states relating to electromagnetic compatibility according to RL2004/108/EG and European Low Voltage Directive RL2006/95/EG.

 Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
 - Increase the separation between the equipment and receiver.
 - Connect the equipment to an outlet on a circuit different from that to which the receiver is connected.
 - Consult the dealer or an experienced radio/TV technician for help.
- Changes or modifications not expressly approved by the complying party may cause the user to lose permission to operate the device.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

- 1) This device may not cause harmful interference, and
- 2) This device must accept any interference received, including interference that may cause undesired operation.



This symbol indicates that this product should not be disposed of with your household waste, according to the WEEE directive (2012/19/EU) and your national law. This

product should be handed over to an authorized collection site for recycling waste electrical and electronic equipment (WEEE). Improper handling of this type of waste could have a possible negative impact on the environment and human health due to potentially hazardous substances that are generally associated with WEEE. At the same time, your cooperation in the correct disposal of this product will contribute to the effective usage of natural resources. For more information about where you can drop off your waste equipment for recycling, please contact your local city office, waste authority, or your household waste disposal service.

■ About This Manual

This manual contains up-to-date technical specifications as of printing. However, specifications contained herein may not conform to your particular product since Takstar is constantly improving its products. Also, specifications, devices or accessories available may vary from region to region. If you have any questions, please contact our local sales outlet. For the latest version/more information, please visit our website: <https://www.takstar.com/>

Copyright ©2026 TAKSTAR. TAKSTAR, 得胜 and their respective logos are registered trademarks or trademarks of Takstar company in the PRC, and/or other countries. All other trademarks are the property of their respective owners.

注意事项：

1. 本单为保修凭证，请用户妥善保管，如有遗失，恕不保修或退换。
2. 保修期限制：购买之日起十二个月内。
3. 除了不可抗力事件损坏外，由本公司负责，免费维修。
4. 如属保管不善或使用不当造成的损坏，维修点将酌情收费。
5. 擅自拆卸维修者，不予保修。
6. 以上保修条款仅限于中国市场适用（不含港澳台地区）。

产品服务保证书

姓名：_____ 电话：_____ 地址：_____

商品：_____ 型号：_____ 购买日期：_____ 年 ____ 月 ____ 日

维修记录栏（由维修员填写）	维修员签名	日期

◆广东得胜电声有限公司 ◆电话：400-6828-333 ◆地址：中国广东省惠州市博罗县龙溪街道夏寮村委会大门村夏照（得胜创业园）



扫一扫，了解更多产品

Scan for more
product information

广东得胜电声有限公司制造

地址: 中国广东省惠州市博罗县龙溪街道夏寮村委会
大门村夏照(得胜创业园)

服务热线: 400 6828 333 传真: 0752 6383950

邮箱: xs@takstar.com

网址: www.takstar.com

Designed & Manufactured by:

Guangdong Takstar Electroacoustic Co., Ltd.

Address: Takstar Innovation Park, Xiazhao,
Damen Village, Xialiao Village Committee,
Longxi Street, Boluo County, Huizhou City,
Guangdong, P.R. China

Tel: 86 752 6383644 Fax: 86 752 6383952

Email: sales@takstar.com

Website: www.takstar.com