TAKSTAR®得胜

欢迎使用MG-620W壁挂音箱,使用前请你仔细阅读说明书,以便能正确的操作使用。

若存在疑问或你有宝贵的建议,可通过拨打得胜官方服务热线 400 6828 333 或微信扫描二维码关注得胜官方公众号与我们联系。



■ 产品特性

- 音箱采用一只6.5寸低音和一只1寸球顶高音单元,频响范围宽
- 音质清澈动听,音乐播放频响均衡
- 箱体采用ABS塑料,质量轻,抗腐蚀强

■ 适用场合

各种室内场所使用,如学校教室、商场等

■ 技术参数

• 额定功率(AES):10W/20W

频率响应:110Hz-12KHz

· 灵敏度:87dB

· 输入电压:110V

• 接线方式:按压式接线盒

· 产品尺寸:182*115*270mm

· 净重:1.15kg

■ 安全警示

为避免电击、高温、着火、辐射、爆炸、机械危险以及使用不当等可能造成的人身伤害或财产损失,使用本产品,请仔细阅读并遵守以下事项:

- 1. 使用产品时请确认所连接设备与本产品功率是否匹配以及合理调整音量大小,不要在超过产品功率及大音量下长时间使用,以免造成产品异常和听力损伤;
- 2.使用中若发现有异常(冒烟、异味等),请立即关闭电源开关并拔掉电源插头,然后将产品送经销商检修;
- 3.本产品及附件都应放置在室内干燥通风处,勿长期存放在潮湿,灰尘多的环境,使用中避免靠近火源、雨淋、进水、过度碰撞、抛掷、振动本机及覆盖通风孔,以免损坏其功能;
- 4.若产品需要固定于墙壁或天花板上时,请确保固定到位,防止因固 定强度不足导致产品发生跌落危险;
- 5.使用该产品时需遵守相关安全规定,法律法规明确禁止使用场合 请勿使用本机,以免导致意外事故。

注意事项:


- 1. 本单为保修凭证,请 用户妥善保管,如有 遗失,恕不保修或退 换。
- 2. 保修期限制: 购买之 日起十二个月内。 3. 除了不可抗力事件损 坏外,由本公司负责:
- 3.除了个可执力事件频 坏外,由本公司负责, 免费维修。 4.如属保管不善或使用 不当造成的损坏,维 修点将酌情收费。
- 修点将酌情收费。 5. 擅自拆卸维修者,不 予保修。
- 6. 以上保修条款仅限于 中国市场适用(不包 含港澳台地区)。

产品服务保证书

维修员签名	日期
	维修员签名

◆广东得胜电子有限公司 ◆电话: 400-6828-333 ◆地址: 广东省惠州市博罗县龙溪街道富康一路2号


■ 产品尺寸图





邮編: 516121传真: 0752-6383950全国服务热线: 400 6828 333邮箱: xs@takstar.com







Thank you for purchasing MG-620W Wall Speaker. To correctly use the device, please read the manual thoroughly.

If you have any questions or suggestions, please contact our local dealer.

■ Features

- Equipped with a 6.5-inch woofer and a 1-inch dome tweeter for a wide frequency response.
- Delivers clear, captivating sound with balanced music playback response.
- Lightweight ABS plastic enclosure ensures durability and corrosion resistance.

■ Applications

or various indoor settings, including school classrooms, and shopping malls

■ Technical Specifications

· Rated Power (AES): 10W/20W

• Frequency Response: 110Hz-12KHz


Sensitivity: 87dBInput Voltage: 110V

Wiring Method: Push-type terminal

Product Size: 182*115*270mm

Net Weight: 1.15kg

Dimensions



■ Safety Instructions

To avoid electric shock, overheat, fire, radiation, explosion, mechanical risk and injury or property loss due to improper use, please read and observe the following items before use:

- Please check if the power of the connected equipment matches with that of this product before operation. Adjust the volume to proper level during operation. Do not operate at over-power or high-volume level for extended time to avoid product malfunction.
- If there is any abnormality during use (e.g., smoke, strange odor), please kill the power switch and unplug from power source, then send the product to the local dealer for repair.
- Keep this product and its accessories in a dry and ventilated area. Do not store in a humid or dusty area for extended time. Keep away from fire, rain, liquid intrusion, bumping, throwing, vibrating, or from blocking any ventilation openings, to prevent malfunction.
- The product must, when installed on walls or ceilings, be fixed firmly in place at adequate strength to prevent from falling.
- Please abide by safety rules during operation. Do not use the product in places prohibited by laws or regulations to avoid accident.